LOADING INSTRUCTIONS

Required Hardware

Commodore 64 computer
VIC 1541 disk drive
TV (or monitor with 5-pin DIN audio cable)

1. Be sure your computer and disk drive are turned OFF.
2. Turn ON the disk drive. The red error light comes on briefly; the green light indicates that power to the drive is on.
3. When the red error light on the disk drive goes out, open the drive door. Insert the program disk with the label facing up. Close the door.
4. Turn ON the TV or monitor, then turn ON the computer.
5. As soon as you see the word READY on the screen, type LOAD "SAT",8 and press the RETURN key. The screen displays the message SEARCHING FOR SAT, followed by the word LOADING.
6. When the word READY reappears on the screen, type RUN and press RETURN. The title screen appears for a few moments, followed by the Color Selection Menu.
7. Press the f 1, f 3 or f 5 key to change the color of the text, background or border, respectively. When finished, press RETURN to go to the Main Menu.

NOTE: If you are using a module in the HAYDEN SAT SCORE IMPROVEMENT SYSTEM that contains more than one disk, always load the disk marked "Program Disk" first. A message on the screen will inform you whenever it is time to insert one of the other disks.